



NEX Diagram of hopper installation sections


■ Injection type 12E



■ Injection type 18E



■ Injection type 25E



■ Injection type 36E

